

Wizard CompSpec C2 Assembly Instructions



Parts Needed

Truck assembly from previous steps

Bag B

(1) part# ott-tko10-019 Front Lower Link x1

(2) part# ott-tko10-086 M3 x 0.5 x 35mm button head screw x1

Step 3

Insert Front Lower Link (1) into Skid (3)

Insert M3 x 0.5 x 35mm screw (2) through chassis (4) and into skid (3) then tighten completely

Tighten M3 x 0.5 x 35mm screw (5) from step 2

