

Wizard CompSpec C2 Assembly Instructions



Parts Needed

Truck assembly from previous steps

Bag K

(1) part# ott-tko10-096 Hero Nano 83-93mm Upper Driveshaft x1

Step 36

blue threadlock is recommended on all threads

Remove body clips (5) from Spur Gear Mount Shaft (4) and input shaft of T-case (3)

Install Hero Nano Upper Driveshaft (1) onto input shaft of T-Case (3) then insert and tighten the driveshaft pin (2)

Install Hero Nano Upper Driveshaft (1) onto Spur Gear Mount Shaft (4) then insert and tighten the driveshaft pin (2.1)

